
ENKEL 4

230V MAX. 4 x 15W E27

Assembly instructions

WARNING: Assembly lamp with the power off.
1. Attach the lamp mounting bracket to the ceiling.
2. Connect the power cables to the connection block, tighten clamp screws, close the connection block.
3. Mount the light sources in the bulb holders.
4. To change the position of the lamp with the mounting cables, unscrew the cable lock. To remove the cable from the lock - press the cable lock.



Used or broken electrical equipment must not be thrown into the trash bin together with other waste. Used device should be taken to a point of separate collection of municipal waste or a point of utilization of electrical equipment. Proper waste segregation is a very important aspect of environmental protection and must be strictly observed.

WARNING: The installation should be performed by a qualified electrician.

Nowodworcowa 15, 81-581 Gdynia, tel. +48 736_812_848, info@ummo.pl

UMMO
LIGHTING